

AT-3100K **GAV** HAVALI MİKRO KALIPÇI TAŞLAMA

Free Speed: 35000 rpm

Collet Size: 0.5 - 5mm


Working Pressure: 90 psi

OPERATION INSTRUCTION

- 1.Set up selected grinding tools on the chuck of the air grinder
- 2.Connected the air line accessory at the end of air hose.
- 3.Turn on slowly and gradually clockwise the variable speed switch in silver color when start the motor.
- 4.Turn off counter clockwise the variable speed switch in silver color when stop the motor.

CAUTION

Please pay attention to operation when turing on the silver variable switch to keep the speed slowly and gradually so that to maintain the motor always in operable condition.



1. COMPACTION
2. CLAMPING NUT
3. FRONT COVER
4. BEARING
5. BUSHING
6. BUSHING

7. BEARING
8. LATERAL DISC
9. SPACER
10. CYLINDER
11. ROTOR
12. FIBRE VANES

13. BEARING
14. BEARING PLATE
15. SLEEVE
16. O-RING
17. INTAKE TIE-IN
18. HOSE PLUG

19. O-RING
20. KNOB IN-HOUSE SLIPCOVER
21. O-RING
22. SLIDING
23. O-RING
24. REAR END HOLDER