


OS-16850L **GAV** HAVALI AVUÇ TAŞALAMA



| No. | Part.No. | Parça Adı | No. | Part.No. | Parça Adı |
|-----|----------|------------------------|-----|-----------|---------------------|
| 1 | 61901 | Motor Housing | 29 | 60319 | Retaining Ring |
| 2 | 61902 | Spring Pin | 30 | 61930 | Bevel Gear |
| 3 | 30103 | Air Inlet | 31 | 61931 | Wave Washer |
| 4 | 61904 | Throttle Lever | 32 | 061932 | Ball Bearing |
| 5 | 61905 | Valve Stem | 33 | 619533A | Spindle (M14) |
| 6 | 61906 | Bushing | 34 | 61934 | Key |
| 7 | 61907 | O-Ring (2) | 35 | 61935 | Gasket |
| 8 | 61908 | Valve Spring | 36 | 619536A | Retainer |
| 9 | 61909 | Throttle Valve Housing | 37 | 619537 | Disc Cover |
| 10 | 61910 | Throttle Lever Plug | 38 | 5D-619239 | Flange (M14) |
| 11 | 60307 | O-Ring | 40 | 5D-619240 | Flange Nut (M14) |
| 12 | 61912 | Plunger | 41 | 61941 | Adjust Screw |
| 13 | 030120 | Ball Bearing (2) | 42 | 61942 | Adjust Nut |
| 14 | 61914 | End Plate | 43 | 40343-12 | Screw (4) |
| 15 | 61915 | Rotor | 44 | 40344 | Spring Washer (4) |
| 16 | 61916 | Vanes (4) | 45 | 61945 | Spring |
| 17 | 40317-14 | Spring Pin | 46 | 61946 | Governor |
| 18 | 61918 | Cylinder | 47 | 61947 | Pendulum (6) |
| 19 | 61919 | Front End Plate | 48 | 40317-13 | Spring Pin (2) |
| 20 | 080227 | Ball Bearing | 49 | 61949 | O-Ring |
| 21 | 61921 | Lock Nut | 50 | 61950 | Torsion Spring |
| 22 | 61922 | Bevel Gear | 51 | 61951 | Throttle Lever Lock |
| 23 | 61923 | Coupling Nut | 52 | 40337 | Spring Pin |
| 24 | 40309 | Screw (2) | 53 | 619553A | Spanner |
| 25 | 61925 | Deflector | 54 | 619554 | Pin Wrench |
| 26 | 61926 | Spacer | 55 | 61955 | Handle |
| 27 | 61927 | Screw | 56 | 52236 | O-Ring |
| 28 | 030113 | Ball Bearing | *57 | 619539 | Grinding Wheel |