


OS-6338IS **GAV** HAVALI TORNAVİDA



| FIG NO. | PART NO. | DESCRIPTION | PCS | FIG NO. | PART NO. | DESCRIPTION | PCS |
|---------|----------|---------------------|-----|---------|----------|------------------------|-----|
| 1 | 389501 | Inlet Bushing | 1 | 21 | 633818IP | Front Plate | 1 |
| 2 | 633802 | Deflector | 1 | 21-1 | 633842 | Spring Pin (2.5X4) | 1 |
| 3 | 389503 | Valve Spring | 1 | 22 | BB608ZZ | Ball Bearing | 1 |
| 4 | 328804V | Valve | 1 | 23 | 556015 | Motor Spacer | 1 |
| 5 | 328835 | Valve Seat | 1 | 24 | 633844 | Impact Adaptor Ring-M2 | 1 |
| 6 | 328825S | Spacer | 1 | 25 | 556013 | Hammer Cage | 1 |
| 7 | 389507 | Silencer | 1 | 26 | 556014 | CAM | 1 |
| 8 | 633808 | Composite Housing | 1 | 27 | 633846IP | Hammer | 1 |
| 9 | 633809 | Reverse Valve Lever | 1 | 28 | 556011 | Hammer Pin | 2 |
| 9-1 | 633809-1 | Screw | 1 | 29 | 633822IS | Anvil | 1 |
| 10 | 633810 | Trigger | 1 | 30 | 556004 | Bushing | 1 |
| 10-1 | 638013 | O-Ring | 1 | 31 | 556003 | Spacer | 1 |
| 11 | 633811 | O-Ring | 2 | 32 | 556002 | Hammer Case Bushing | 1 |
| 12 | 633812 | Valve Body | 1 | 33 | 633845 | Hammer Case | 1 |
| 13 | 633847 | Spring | 1 | 34 | STB3175 | Steel Ball | 1 |
| 14 | SB0003-1 | Detent Ball | 1 | 35 | 556009 | Retaining Sleeve | 1 |
| 15 | B626ZZ | Ball Bearing | 2 | 36 | S1112 | Spring | 1 |
| 16 | 633813 | Rear Plate | 1 | 37 | 556007 | QC.Spacer | 1 |
| 17 | 633817-1 | Guide Pin | 1 | 38 | 589033 | Spring Holder | 1 |
| 18 | 633815IS | Rotor | 1 | | | | |
| 19 | 633816 | Rotor Blade | 6 | | | | |
| 20 | 633817 | Cylinder | 1 | | | | |